

CHANDELIER CARE

ON CLEANING

Make sure that lamp is cool and switched off. For general everyday cleaning, use a soft antistatic dust brush or microfiber.

For cleaning stubborn layers of dust, use a gentle solvent free cleanser with paper towels or a microfiber cloth. We recommend to use cotton gloves when handling the fixture.

Avoid rotating your chandelier. When cleaning, walk or move your ladder around your light fixture.

GENERAL NOTE

The canopy system should not be exposed to water or wind, or be allowed to oscillate/rotate continuously in any circumstance. Avoid placing fixtures close to HVAC vents or in chemical-laden environments such as indoor swimming pools.

HVAC WARNING: Do not place pendant fixtures in moving-air environments unless they are laterally/ seismically braced. Continuous oscillation/rotation may cause fixture to unthread from its supports, leading to suspension failure.

WARRANTY

PELLE warrants its products to be free of defects in workmanship under normal use and service for a period of one year from date of purchase. PELLE reserves the right to inspect the damaged product before having any obligation under this limited warranty. All costs of shipping for inspection are the sole responsibility of the purchaser. PELLE, at it's option, shall repair or replace the defective unit covered by this warranty. PELLE is not responsible for damages caused by improper installation, maintenance or operation. Removing warning labels from the fixture or any other modification to the fixture not performed by manufacturer voids the warranty. Our warranty extends to products purchased only by the original purchaser.